



KONICA MINOLTA

bizhub i-SERIES IS SMARTER WORKING RETHINK IT



bizhub 751i
Black & White multifunctional



Konica Minolta Business Solutions U.S.A., Inc.
2025 A3 Line of the Year Award

Giving Shape to Ideas

CUSTOMER BENEFITS



Intuitive operability
Operate the bizhub like a smartphone or tablet with fully customizable user interface



Mobile connectivity
Print anytime from anywhere with Konica Minolta's innovative mobile technologies



Security
Secure network integration, data encryption, and advanced user authentication



Application ecosystem
Enhanced efficiency thanks to Konica Minolta's extensive applications portfolio



Productivity
Reliability, high-speed scanning and printing, combined with powerful finishing functions



Sustainability
Numerous eco features reduce energy consumption and costs

OPTIONS

1 ENHANCED FEATURES

- Voice Guidance LK-104v3
- Barcode fonts LK-106
- Unicode fonts LK-107
- OCR A and B fonts LK-108
- Document converter pack LK-110v2
- ThinPrint® client LK-111
- Antivirus LK-116



2 CONNECTIVITY

- Fax board FK-514 x2
- Wireless LAN UK-221
- USB I / F kit EK-608
- USB I / F kit EK-609 OR
- ID card reader AU-205H
- Mount kit MK-735

3 OTHERS

- Working table WT-506
- 10-Key pad KP-102
- Security kit SC-509
- Replacement SSD EM-908
- Keyboard holder KH-102
- Convenience Stapler CS-2

4 MEDIA INPUT

- Intelligent media Sensor IM-103
- Large capacity tray LU-303 OR
- Large capacity tray LU-205
- Banner tray MK-730

5 MEDIA OUTPUT

- Output tray OT-514 OR
- Off-line stapler FS-P04
- Staple finisher FS-539 OR
- Relay unit RU-519 OR
- Booklet finisher FS-539SD OR
- Relay unit RU-519 OR
- Punch kit for FS-539/SD PK-524
- Staple finisher FS-540 OR
- Relay unit RU-519 OR
- Booklet finisher FS-540SD OR
- Relay unit RU-519 OR
- Punch kit for FS-540/SD PK-526 OR
- Post inserter for FS-540/SD PI-507 OR
- Job separator for FS-540/SD JS-602 OR
- Z-fold unit for FS-540/SD ZU-609

LEGEND

- Mandatory option
- Option
- This option can only be installed with the respective option above it

FINISHING FUNCTIONALITIES

- Corner stapling**
- Two-point stapling**
- Two-hole punching**
- Three-hole punching**
- Duplex**
- Combined mixplex/mixmedia**
- Half-fold**
- Sheet insertion**
- Tri-fold**
- Booklet**
- Offset sorting**
- Z-fold**
- Banner printing**
- Corner Stapling (offline)**

DESCRIPTION

ENHANCED FEATURES

LK-104v3 Voice Guidance	Provides voice guidance in select screens
LK-106 Barcode fonts	Supports native barcode printing
LK-107 Unicode fonts	Supports native Unicode printing
LK-108 OCR A and B fonts	Supports native OCR A and B font printing
LK-110v2 Document converter pack	Supports Searchable PDF and OOXML (DOCX, XLSX, etc.) file formats
LK-111 ThinPrint® client	Print data compression for reduced network impact
LK-116 Antivirus	Bitdefender® antivirus provides real time scanning of all incoming and outgoing data

CONNECTIVITY

FK-514 Fax board	Super G3 fax, digital fax functionality
UK-221 Wireless LAN	Wireless LAN and wireless LAN Access Point Mode
EK-608 USB I/F kit	USB keyboard connection
EK-609 USB I/F kit	USB keyboard connection; Bluetooth
AU-205H ID card reader	Various ID card technologies
MK-735 Mount kit	Installation kit for ID card reader

OTHERS

WT-506 Working table	Authentication device placement
WT-519 Working table	Working table for upright panel
KP-102 10-Key pad	For numeric entry instead of touchscreen
SC-509 Security kit	Copy guard function
EM-908 1 TB SSD	1 TB SSD to increase storage space
KH-102 Keyboard holder	To place USB keyboard
External Keyboard	Keyboard for alpha numeric data entry
CS-2 Convenience Stapler	50 Sheet stapler

MEDIA INPUT

IM-103 Intelligent Media Sensor	Detects paper type and weight automatically
LU-303 Large capacity tray	3,000 sheets, 8.5" x 11"; 52–256 g/m ²
LU-205 Large capacity tray	2,500 sheets, 8.5" x 11" - 12" x 18"; 52–256 g/m ²
MK-730 Banner tray	Multipage banner feeding

MEDIA OUTPUT

OT-514 Output tray	Output tray used instead of finisher
FS-539 Staple finisher	50-sheet stapling; 3,200 sheets max. output
FS-539SD Booklet finisher	50-sheet stapling; 20-sheet booklet finisher; 2,200 sheets max. output
PK-524 Punch kit for FS-539/SD	2/3-hole punching; auto switching
FS-540 Staple finisher	100-sheet stapling; 3,200 sheets max. output
FS-540SD Booklet finisher	100-sheet stapling; 20-sheet booklet finisher; 2,700 sheets max. output
PK-526 Punch kit for FS-540/SD	2/3-hole punching; auto switching
RU-519 Relay unit	For FS-539/SD or FS-540/SD installation
PI-507 Post inserter for FS-540/SD	Cover insertion; post finishing
JS-602 Job separator for FS-540/SD	Separation of fax output; etc.
ZU-609 Z-fold unit for FS-540/SD	Z-fold for 11" x 17" prints
FS-P04 Off-line stapler	20-sheet off-line stapling

TECHNICAL SPECIFICATIONS

SYSTEM SPECIFICATIONS

System speed letter	Up to 75
System speed 11" x 17"	Up to 37
Auto duplex speed letter	Up to 75
1st page out time letter	2.8/3.8 sec.
Warm-up time	Approx. 17 ¹
Imaging technology	Laser
Toner technology	Simitri® HD polymerized toner
Panel size/resolution	10.1" / 1024 x 600
System memory	8 GB (standard/max)
Solid state drive	256 GB SSD (standard) / 1 TB SSD (optional)
Interface	10/100/1,000-Base-T Ethernet; USB 2.0; Wi-Fi 802.11 b/g/n/ac (optional)
Network protocols	TCP/IP (IPv4 / IPv6); SMB; LPD; IPP; SNMP; HTTP(S); Bonjour
Automatic document feeder	Up to 300 originals/ 5.5" x 8.5"-11" x 17"/35–210 g/m ² /Dual scan ADF
ADF double feed detection	Standard
Printable paper size	3.5" x 5.5" - 12" x 18"; custom paper sizes, banner paper max. 47.25" x 11.7"
Printable paper weight	52–300 g/m ²
Paper input capacity	3,650 sheets / 6,650 sheets (standard/max)
Paper tray input (standard)	1x 500; 3.5" x 5.5" - 11" x 17"; custom sizes; 52–256 g/m ² 1x 500; 5.5" x 8.5" - 12" x 18"; custom sizes; 52–256 g/m ² 1x 1,500; 5.5" x 8.5" - 11" x 17"; 52–256 g/m ² 1x 1,000; 5.5" x 8.5" - 11" x 17"; 52–256 g/m ²
Manual bypass (standard)	150 sheets; 3.5" x 5.5" - 12" x 18"; custom sizes; banner; 60–300 g/m ²
Large capacity tray (optional)	1x 3,000; 5.5" x 8.5" - 11" x 17"; 52–256 g/m ² 1x 2,500; 8.5" x 11" - 12" x 18"; custom sizes; 52–256 g/m ²

SYSTEM SPECIFICATIONS

Finishing modes (optional)	Offset; Group; Sort; Staple; Staple (offline); Punch; Half-fold; Tri-fold; Booklet; Post insertion; Z-fold
Automatic duplexing	3.5" x 5.5" - 12" x 18"; 52–256 g/m ²
Output capacity	Up to 200 sheets / up to 3,300 sheets (standard/max)
Stapling	Max. 100 sheets or 98 sheets + 2 cover sheets (up to 300 g/m ²)
Stapling output capacity	Max. 200 sets
Tri-fold	Max. 3 sheets
Tri-fold capacity	Max. 50 sets; unlimited (without tray)
Booklet	Max. 20 sheets or 19 sheets + 1 cover sheet (up to 300 g/m ²)
Booklet output capacity	Max. 35 booklets; unlimited (without tray)
Duty cycle (monthly)	Max. ² 300,000 pages
Toner lifetime	Black up to 45,000 pages
Imaging unit lifetime	Black up to 240,000/1,000,000 pages (drum/developer)
Power consumption	110–120V/ 50/60 Hz; Less than 2.10 kW
System dimension (W x D x H)	24.2" x 27.1" x 47.5" (without options)
System weight	Approx. 307 lbs. (without options)

PRINTER SPECIFICATIONS

Print resolution	1,800 (equivalent) x 600 dpi; 1200 x 1200 dpi
Page description language	PCL 6 (XL3.0); PCL 5c; PostScript 3 (CPSI 3016); XPS
Operating systems	Windows 10 (32/64); Windows 11; Windows Server 2016; Windows Server 2019; Windows Server 2022; macOS 11 or later; Unix; Linux; Citrix
Printer fonts	80 PCL Latin; 137 PostScript 3 Emulation Latin
Mobile printing	AirPrint (iOS); Mopria (Android); Konica Minolta Print Service (Android); Konica Minolta Mobile Print (iOS/Android) Optional: Wi-Fi Direct

SCANNER SPECIFICATIONS

Scan speed	Up to 140/140 ipm in simplex (mono/color) Up to 280/280 ipm in duplex (mono/color)
Scan resolution	Up to 600 x 600 dpi
Scan modes	Scan-to-eMail (Scan-to-Me); Scan-to-SMB (Scan-to-Home); Scan-to-FTP; Scan-to-Box; Scan-to-USB; Scan-to-WebDAV; Scan-to-DPWS; Scan-to-URL; TWAIN scan
File formats	JPEG; TIFF; PDF; Compact PDF; Encrypted PDF; XPS; Compact XPS; PPTX optional: Searchable PDF; PDF/A 1a and 1b; Searchable DOCX/PPTX/XLSX
Scan destinations	2,000 destinations + 100 groups; LDAP support

COPIER SPECIFICATIONS

Copy resolution	600 x 600 dpi
Gradation	256 gradations
Multicopy	1-9,999
Original format	Max. 11" x 17"
Magnification	25-400% in 0.1% steps; Auto-zoom

FAX SPECIFICATION

Fax standard	Super G3 (optional)
Fax transmission	Analog; i-Fax; Color i-Fax
Fax resolution	Up to 600 x 600 dpi
Fax compression	MH; MR; MMR; JBIG
Fax modem	Up to 33.6 Kbps
Fax destinations	2,000 single + 100 groups

USER BOX SPECIFICATIONS

Storable documents	Up to 3,000 documents or 10,000 pages
User boxes	Public; Personal (with password or authentication); Group (with authentication)
System boxes	Secure print; Encrypted PDF print; Fax receipt; Fax polling



For complete information on Konica Minolta products and solutions, please visit: CountOnKonicaMinolta.com

SYSTEM FEATURES

Security	ISO 15408 HCD-PP Common Criteria; IP filtering and port blocking; SSL3 and TLS1.0/1.1/1.2 network communication; IPsec support; IEEE 802.1x support; User authentication; Authentication log; Secure print; Kerberos; Overwrite all data function; SSD Self-Encryption (AES 256)/Storage lock password; Confidential fax; Print user data encryption
Security function (optional)	Antivirus realtime scanning (Bitdefender®); Copy protection (Copy Guard; Password Copy)
Accounting	Up to 1,000 user accounts; Active Directory support (user name + password + e-mail + smb folder); User function access definition; Authentication by mobile device (Android) ID card authentication (ID card reader); Authentication by mobile device (iOS)
Software	Net Care Device Manager; Data Administrator; Web Connection; Log Management Utility

¹ Warm-up time may vary depending on the operating environment and usage
² If the maximum volume is reached within a period of one year, then a maintenance cycle must be performed

- All specifications refer to 8.5" x 11"-size paper of 80 g/m² quality.
- The support and availability of the listed specifications and functionalities varies depending on operating systems, applications and network protocols as well as network and system configurations.
- The stated life expectancy of each consumable is based on specific operating conditions such as page coverage for a particular page size (5% coverage of 8.5" x 11"). The actual life of each consumable will vary depending on use and other printing variables including page coverage, page size, media type, continuous or intermittent printing, ambient temperature and humidity.
- Some of the product illustrations contain optional accessories.
- Specifications and accessories are based on the information available at the time of printing and are subject to change without notice.
- Konica Minolta does not warrant that any specifications mentioned will be error-free.
- All brand and product names may be registered trademarks or trademarks of their respective holders and are hereby acknowledged.